


# INSTALLATION INSTRUCTIONS

## 1096M Adjustable Door Closer

Part Number: 11096M00004

 Your Kason 1096M Door Closer is a high tension device. Caution must be exercised while mounting and adjusting. Please follow the instructions below.

### 1. Flush Doors (Fig. 1)

Align the side of the plate with the edge of the jamb.

### Offset Doors (Fig. 2)

Align the side of the plate with the edge of the door.

A. Mark starting hole

B. Install door closer as shown on door jamb with 1/4" fasteners

2. Determine roller guide location for door application, open door and place roller guide under torque arm. Use 2" dimension as a starting point to ensure roller guide stays in contact throughout door range of motion (Fig. 3). Install roller guide on door as shown using 1/4" fasteners.
- Note:** Cam rise hinges require the assembly to be mounted as shown to accommodate door rise.

3. Open door fully to check function and clearance of parts before winding door closer.

### 4. To Wind

Turn hex nut on end of cylinder with 5/8" wrench in direction of arrows. Right hand installation turns clockwise (Fig. 3) and left hand installation turns counterclockwise (Fig. 4).

**Note:** Pin will index one notch at a time; 8 positions max.

### 5. To Unwind

- A. Turn 5/8" hex nut in direction of arrows slightly to remove load from pin
- B. While holding load, pull the pin out (pin should move freely when there is no load on it)
- C. Slowly let wrench rotate opposite from arrows and release pin: pin will automatically find next index spot
- D. Repeat steps A-C until no tension is left on closer

Fig. 1




Fig. 2




Fig. 3




Fig. 4



For LEFT HAND DOOR, mount unit upside down on lower left hand door jamb, as shown here. \*Follow the left hand winding procedure.



**GreenGuard®**